



My Wireless TV

Software Upgrade Notice

Actiontec recommends that all MyWirelessTV users update their components with the latest software to take advantage of recently developed performance enhancements and new features.

The following products need to have a software upgrade applied:

- Wireless HD Video Kit (model # MWTV200KIT)
- Wireless HD Video Receiver (model # MWTV200R)
- Wireless HD Video Transmitter (model # MWTV200T)

To obtain the latest software and information, visit the product website at:

<http://www.actiontec.com/mwTV>

For technical support call

1-888-436-0657

Software Upgrade Instructions

Software update requirements

- USB thumb drive
- USB mini-adapter (provided with MWTV200KIT)
- Desktop or laptop computer with 30mb of available hard drive space
- Web browser

How to update your MWTV components:

- 1** Using a web browser, go to <http://www.actiontec.com/mwttv>
- 2** Follow the online instructions to download the latest MyWirelessTV firmware to the USB thumb drive.
- 3** Once the firmware is downloaded to the thumb drive:
 - On the Receiver, plug the USB thumb drive into the USB port on the front of the Receiver. Power off, then on to start the upgrade.
 - On the Transmitter, plug the USB thumb drive into the larger end of the USB mini-adapter, then plug the smaller end of the mini-adapter into the USB mini-port on the front of the Transmitter. Power off, then on to start the upgrade.
- 4** The Power and Sync LEDs will flash for 2-3 minutes. **Important!:** Do not power down or remove the USB thumb drive while the LEDs are flashing.
- 5** After the LEDs turn off briefly, the Power LED will flash, then glow solid green. When this occurs, remove the thumb drive from the MWTV component.
- 6** Repeat steps 3-5 for all MWTV components that need an update.
- 7** Once the software update has been applied to all MWTV components, perform a power cycle (turn off, then on) on all components. The MWTV components will pair automatically, streaming audio and video.

The software update has been successfully applied. To view the current firmware version number, press the Menu button on the MWTV remote control, then select Advanced Settings.

Visit our website for video instructions